

Paper & Paperboard Testing Program

Summary Report #3022 G - October 2019

[Introduction to the Paper & Paperboard Interlaboratory Program](#)

[Explanation of Tables and Definitions of Terms](#)

<u>Analysis</u>	<u>Analysis Name</u>
350	Color & Color Difference - Near White Papers - C/2deg obs
351	Color & Color Difference - Near White Papers - D65/10deg obs
360	Thickness (Caliper), Printing papers
361	Thickness (Caliper), Packaging papers
364	Coefficient of Static Friction - Horizontal Plane Method - Printing Papers
365	Coefficient of Kinetic Friction - Horizontal Plane Method - Printing Papers
370	Air Resistance - Gurley Oil Type
372	Porosity - Sheffield Type - Sheffield Units for 3/4 inch Diameter Orifice
376	Roughness - Print Surf Method - 0.5 to 4.0 Microns
377	Roughness - Print Surf Method - 2.5 to 6.0 Microns
378	Roughness - Sheffield Type
382	Moisture in Paper
384	Opacity (89% Reflectance Backing) - Fine Papers
386	Opacity (Paper Backing) - Fine Papers and Newsprint
390	Directional Brightness
391	Directional Brightness of Fluorescent Samples
392	Diffuse Brightness
394	Fluorescent Component of Directional Brightness
395	Specular Gloss at 75 Degrees - High Range
396	Specular Gloss at 75 Degrees - Low Range
398	Grammage (Mass per Unit Area)
399	Sizing Test (Hercules Type)

The CTS Paper & Paperboard Interlaboratory Program

In 1969, the National Bureau of Standards (now designated the National Institute for Standards and Technology) and the Technical Association of the Pulp and Paper Industry (TAPPI) developed an interlaboratory program for paper and paperboard testing. Since 1971, Collaborative Testing Services has operated the Collaborative Reference Program for Paper and Paperboard. With hundreds of organizations from around the world participating in these tests, this program has become one of the largest of its kind. The program allows laboratories to compare the performance of their testing with that of other participating laboratories, and provides a realistic picture of the state of paper testing.

About CTS

Founded in 1971, Collaborative Testing Services, Inc. (CTS) is a privately - owned company that specializes in interlaboratory tests for a variety of industrial sectors: rubber, plastics, fasteners and metals, CKPG, paper, color and wine, as well as proficiency tests for forensic laboratories. All of the tests are designed to assist organizations in achieving and maintaining quality assurance objectives. Labs from the U.S., as well as more than 80 countries, currently participate in CTS programs.

If there are any questions on the report or testing program, please contact:

Collaborative Testing Services, Inc.
21331 Gentry Drive
Sterling, Virginia 20166 USA
+1-571-434-1925
FAX #: +1-571-434-1937
paper@cts-interlab.com

Office Hours: 8:00 a.m. - 4:30 p.m. ET

Key for Web Summary Reports (Page 1 of 2)

WebCode	Assigned laboratory identification number (temporary) used to ensure lab confidentiality while permitting a lab to locate its data in the Paper Report published on the CTS Web site. The WebCode for each analysis can be found on the datasheets and in the Performance Analysis Report mailed to each participant.
Lab Mean	The average of the values obtained for each sample by the participant.
Grand Mean	The average of the LAB MEANS for all included participants. Laboratories flagged with an X or an M (see DATA FLAG column) are excluded from the GRAND MEAN.
ΔE	The calculated total color difference between the two samples. For the Hunter L,a,b analyses it is calculated in Hunter units (ΔE). For the L*,a*,b* analyses it is calculated in CIELAB units (ΔE*).
Difference from Grand Mean	The difference of the LAB MEAN from the GRAND MEAN.
Between-Lab Standard Deviation	An indication of the precision of measurement between the laboratories. The greater the spread of the LAB MEANS about the GRAND MEAN, the larger the BETWEEN-LAB STANDARD DEVIATION (and vice versa).
Comparative Performance Value	An indication of how well a laboratory's results agree with the other participants. The CPV is a ratio indicating the number of standard deviations from the GRAND MEAN. The closer a laboratory's COMPARATIVE PERFORMANCE VALUE is to zero, the more consistent its results are with the other participants' data (and vice versa). The critical value for each CPV will vary depending on the number of labs participating in a test.
Inst Code	A code indicating the manufacturer of the instrument used to perform the test (see separate INSTRUMENT CODE LIST for each test section), if instruments are tracked.
Data Flag	DATA FLAGS are assigned based on the simultaneous analysis of both samples tested. Refer to the following chart for an explanation of each symbol:

<u>DATA FLAG</u>	<u>STATISTICALLY INCLUDED/EXCLUDED</u>	<u>ACTION REQUIRED</u>
*	INCLUDED	CAUTION - review testing procedure and monitor future results. Results fall outside 95% ellipse but within a 99% ellipse that is calculated but not drawn.
X	EXCLUDED	STOP - immediate review of data and/or testing procedure is required. Results fall outside the 99% ellipse. See specific notes following each table for more information on why the data is excluded.
M	EXCLUDED	PROCEED - lab was unable to report data for at least one sample.

Graph - For each laboratory, the LAB MEAN for the first sample (x-axis) is plotted against the LAB MEAN for the second sample (y-axis) with each point representing a laboratory. The horizontal and vertical cross-hairs are the GRAND MEANS for each sample. When 20 or more laboratories are in the statistics, an ellipse is also drawn so that 95% of the time a randomly selected laboratory will be included inside the ellipse. Plotted data flags are explained on the previous page.

Common Problems Highlighted in Footnotes

1. **Extreme data** - The laboratory's results for one or both samples are so inconsistent with those of the other participants that the lab mean(s) fall outside the plot. The participant is advised to immediately review his data and/or testing procedure.
2. **Systematic bias** - The laboratory's results are either consistently high or low for both samples when compared to the other participants (the plotted point falls near the top or bottom of the ellipse). This indicates that the participant is performing the test with a constant bias. Causes of systematic errors include improper calibration, the particular make/model of equipment or a modification to the testing procedure.
3. **Inconsistency in testing between samples/sample sets** - The laboratory's results indicate that there are differences in the way the two samples tested (the plotted point falls to the side of the ellipse). This type of error may be attributed to the analyst deviating from the procedure when testing one of the samples or a material interaction occurrence with the instrument or room conditions. The inconsistency is reflected in the CPVs for the two samples, such as a +1.5 CPV for sample A and a -2.2 CPV for sample B. CTS also will specify if the laboratory's data for one sample are high/low compared to the other participants. If this inconsistency is slight, the lab's plotted point will be an * that falls on the edge of the ellipse.
4. **Inconsistency in testing within a sample** - The laboratory's within-lab standard deviation for a specified sample is high when compared to the other participants, often causing the lab's plotted point to fall outside of the ellipse.

Labs flagged with an * are not typically included in the footnotes of a data table. These labs may locate their position in the control ellipse and use the definitions above to help identify the type of testing error. An * should serve as a caution flag, a "yellow light", to a lab. If this error is repeated in future rounds, a lab may need to stop and review its testing procedures. The initial data flag is not cause for alarm. Interlaboratory tests conducted at regular intervals permit a lab to recognize trends in testing.



**Paper & Paperboard Interlaboratory Testing Program
Analysis 350**

**Report #3022 G,
October 2019**

**Color & Color Difference - Near White Papers - C/2deg obs
Hunter L,a,b - Illuminant C - 2 Degree Observer**

Web Code	Data Flag	Samples	Hunter L, a, b Color Values			Color Difference Values				Instr Code
			L	a	b	ΔL	Δa	Δb	ΔE	
2ZVZGU		GA71	94.00	-0.79	3.98	-0.41	0.03	0.01	0.41	TS
		GA72	93.59	-0.76	3.99					
6ZYUPP		GA71	94.49	-0.72	4.12	-0.40	-0.02	0.11	0.41	HE
		GA72	94.10	-0.74	4.23					
8AGZT8		GA71	94.03	-0.51	3.79	-0.45	-0.01	0.09	0.46	LA
		GA72	93.59	-0.52	3.88					
AQFRRD		GA71	93.26	-0.31	3.51	-0.41	0.03	0.08	0.42	TS
		GA72	92.85	-0.28	3.59					
AYDQZE		GA71	95.37	-0.76	3.81	-0.28	-0.02	0.19	0.34	TC
		GA72	95.09	-0.78	3.99					
FLNTKC		GA71	93.34	-0.25	3.71	-0.34	-0.03	0.10	0.35	TS
		GA72	93.01	-0.28	3.81					
GFU3T7	X	GA71	112.56	-5.41	10.80	-0.66	0.00	0.15	0.68	TS
		GA72	111.90	-5.41	10.96					
KMZ78U		GA71	95.49	-0.78	3.29	-0.32	0.03	0.11	0.34	XS
		GA72	95.17	-0.75	3.40					
NGAQD8		GA71	95.07	-0.80	3.77	-0.56	-0.02	0.12	0.57	HE
		GA72	94.51	-0.82	3.89					
QAU49T		GA71	95.36	-0.85	3.93	-0.32	-0.02	0.14	0.35	LS
		GA72	95.03	-0.87	4.07					
RPQH82		GA71	95.35	-0.82	3.90	-0.37	0.01	0.02	0.37	EH
		GA72	94.98	-0.80	3.92					
TMV8VY		GA71	90.81	-0.75	3.07	0.20	-0.02	0.51	0.55	VM
		GA72	91.01	-0.78	3.58					
VGJATW		GA71	94.05	-0.88	4.11	-0.43	0.01	0.07	0.43	XX
		GA72	93.62	-0.87	4.18					
WU7UXQ		GA71	94.17	-1.13	3.86	-0.16	0.09	0.22	0.29	HG
		GA72	94.01	-1.04	4.08					
YBND3W		GA71	94.84	-0.59	3.72	-0.38	-0.03	0.07	0.38	HE
		GA72	94.46	-0.62	3.79					
ZUAN6L		GA71	94.12	-0.84	3.93	-0.43	-0.01	0.10	0.44	TC
		GA72	93.69	-0.85	4.02					



**Paper & Paperboard Interlaboratory Testing Program
Analysis 350**

**Report #3022 G,
October 2019**

**Color & Color Difference - Near White Papers - C/2deg obs
Hunter L,a,b - Illuminant C - 2 Degree Observer**

Web Code	Data Flag	Samples	Hunter L, a, b Color Values			Color Difference Values				Instr Code
			L	a	b	ΔL	Δa	Δb	ΔE	
ZZHWNC		GA71	95.53	-0.49	3.90	-0.46	-0.02	0.14	0.48	ND
		GA72	95.07	-0.51	4.04					

Grand Means			Summary Statistics							
	GA71	94.330	-0.705	3.775						
	GA72	93.986	-0.705	3.904	-0.344	0.000	0.129	0.412		
Std Dev Btw Labs										
	GA71	1.202	0.224	0.278	0.170	0.033	0.115	0.077		
	GA72	1.097	0.211	0.226						
Statistics based on 16 of 17 reporting participants										

Comments on Assigned Data Flags for Test #350

GFU3T7 (X) - Extremely high data for both "L" and "b" values. Extremely low data for "a" values. High delta "E" value.

Key to Instrument Codes Reported by Participants


EH	Datacolor Elrepho SF450	HE	Hunter LabScan
HG	Hunter ColorQUEST	LA	L & W Elrepho AL300
LS	L & W Elrepho SE 070	ND	Minolta CM-2500d Spectrophotometer
TC	Technidyne Color Touch Series	TS	Technidyne Brightimeter Micro S-5
VM	Valmet PaperLab (was Kajaani/Robotest)	XS	X-Rite 938 Spectrodensitometer
XX	Instrument make/model not specified by lab		



Paper & Paperboard Interlaboratory Testing Program
Analysis 350
Color & Color Difference - Near White Papers - C/2deg obs
Hunter L,a,b - Illuminant C - 2 Degree Observer

Report #3022 G,
October 2019

Plot of L values GA72 vs L values GA71




If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 350
Color & Color Difference - Near White Papers - C/2deg obs
Hunter L,a,b - Illuminant C - 2 Degree Observer

Report #3022 G,
October 2019

Plot of a values GA72 vs a values GA71




If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 350
Color & Color Difference - Near White Papers - C/2deg obs
Hunter L,a,b - Illuminant C - 2 Degree Observer

Report #3022 G,
October 2019

Plot of b values GA72 vs b values GA71



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



**Paper & Paperboard Interlaboratory Testing Program
Analysis 351**

**Report #3022 G,
October 2019**

**Color & Color Difference - Near White Papers - D65/10deg obs
Hunter L,a,b - Illuminant D65 - 10 Degree Observer**

Web Code	Data Flag	Samples	CIE L* a* b* Color Values			Color Difference Values				InstrCode
			L*	a*	b*	ΔL^*	Δa^*	Δb^*	ΔE^*	
38UPYX		GA71	95.05	-0.59	3.98	0.08	-0.02	0.11	0.14	HT
		GA72	95.12	-0.62	4.09					
4AUDQT		GA71	95.56	-0.53	3.96	-0.28	-0.02	0.12	0.31	NF
		GA72	95.28	-0.55	4.08					
638U7P		GA71	94.63	-0.76	3.29	0.10	-0.01	0.49	0.50	NG
		GA72	94.73	-0.76	3.78					
7BJBAJ		GA71	95.44	-0.60	3.98	-0.33	-0.02	0.12	0.36	LS
		GA72	95.11	-0.62	4.10					
7QCZ9M		GA71	95.45	-0.61	4.21	-0.31	-0.03	0.11	0.33	NG
		GA72	95.14	-0.64	4.32					
8WFJPQ		GA71	94.49	-0.79	3.22	0.08	0.00	0.50	0.51	EH
		GA72	94.58	-0.79	3.73					
9GF4XV		GA71	95.21	-0.65	3.84	-0.24	0.03	0.02	0.25	TC
		GA72	94.97	-0.63	3.86					
GRQ6DM		GA71	95.74	-0.58	3.84	-0.32	-0.04	0.10	0.34	HE
		GA72	95.42	-0.62	3.94					
JN3EY3		GA71	94.82	-0.54	3.65	-0.54	-0.03	0.10	0.55	HE
		GA72	94.27	-0.58	3.75					
K2N2R2		GA71	95.13	-0.81	3.56	-0.05	0.02	0.23	0.23	XC
		GA72	95.08	-0.79	3.79					
NGAQD8		GA71	94.69	-0.73	3.85	-0.36	-0.01	0.03	0.37	HE
		GA72	94.33	-0.74	3.88					
PWA2DW		GA71	94.64	-0.91	3.56	-0.28	0.09	0.34	0.45	HE
		GA72	94.36	-0.82	3.90					
Q88HHR		GA71	94.08	-0.47	3.42	-0.37	-0.02	0.17	0.41	XA
		GA72	93.71	-0.48	3.59					
RNFQ3R		GA71	95.40	-0.70	3.88	-0.29	-0.01	0.18	0.35	EF
		GA72	95.11	-0.70	4.07					
TFVY7Y		GA71	96.87	-0.47	3.55	-0.42	0.00	0.17	0.46	XP
		GA72	96.44	-0.47	3.72					
WMLJZP		GA71	95.64	-0.71	3.98	-0.27	-0.03	0.11	0.30	HT
		GA72	95.37	-0.74	4.09					



Paper & Paperboard Interlaboratory Testing Program
Analysis 351
Color & Color Difference - Near White Papers - D65/10deg obs
Hunter L,a,b - Illuminant D65 - 10 Degree Observer

Report #3022 G,
October 2019

XYAXJH	GA71	93.88	-0.56	3.69	-0.35	0.00	0.12	0.38	TC
	GA72	93.52	-0.56	3.82					

Grand Means			Summary Statistics					
GA71	95.101	-0.647	3.733					
GA72	94.854	-0.654	3.911	-0.246	-0.006	0.178	0.365	
Std Dev Btwn Labs								
GA71	0.706	0.125	0.271					
GA72	0.692	0.108	0.188	0.186	0.030	0.140	0.108	
Statistics based on 17 of 17 reporting participants								

Key to Instrument Codes Reported by Participants


EF	Datacolor Elrepho 3000	EH	Datacolor Elrepho SF450
HE	Hunter LabScan	HT	Hunter UltraScan Vis
LS	L & W Elrepho SE 070	NF	Minolta CM-3600d Spectrophotometer
NG	Minolta CM-3700d Spectrophotometer	TC	Technidyne Color Touch Series
XA	X-Rite (model not specified)	XC	X-Rite eXact Series
XP	X-Rite Spectrophotometer DTP		



Paper & Paperboard Interlaboratory Testing Program
Analysis 351
Color & Color Difference - Near White Papers - D65/10deg obs
Hunter L,a,b - Illuminant D65 - 10 Degree Observer

Report #3022 G,
October 2019

Plot of L values GA72 vs L values GA71




If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 351
Color & Color Difference - Near White Papers - D65/10deg obs
Hunter L,a,b - Illuminant D65 - 10 Degree Observer

Report #3022 G,
October 2019

Plot of a values GA72 vs a values GA71




If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 351
Color & Color Difference - Near White Papers - D65/10deg obs
Hunter L,a,b - Illuminant D65 - 10 Degree Observer

Report #3022 G,
October 2019

Plot of b values GA72 vs b values GA71



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 360
Thickness (Caliper), Printing papers
TAPPI Official Test Method T411

Report #3022G,
October 2019

WebCode	Data Flag	Sample GV71			Sample GV72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		4.644	0.045	0.51	4.630	0.024	0.27	TM
2ZVZGU		4.482	-0.117	-1.33	4.502	-0.104	-1.19	LA
38TQZJ		4.596	-0.003	-0.04	4.658	0.052	0.59	LW
38UPYX		4.658	0.059	0.67	4.654	0.048	0.55	EM
4AUDQT		4.715	0.116	1.31	4.724	0.118	1.35	TM
4FG9PC		4.497	-0.102	-1.16	4.511	-0.095	-1.09	PP
638U7P		4.608	0.009	0.10	4.611	0.005	0.06	EM
7QCZ9M		4.567	-0.032	-0.37	4.577	-0.029	-0.33	PP
8AGZT8		4.655	0.055	0.63	4.617	0.010	0.12	EM
8DG7CJ		4.638	0.039	0.44	4.654	0.048	0.55	LA
8WFJPQ		4.746	0.147	1.66	4.742	0.136	1.56	XX
9GF4XV		4.756	0.157	1.77	4.752	0.146	1.67	PP
ARBF73		4.611	0.012	0.13	4.589	-0.017	-0.19	LW
AYDQZE		4.580	-0.019	-0.22	4.583	-0.023	-0.26	LA
B474JH		4.566	-0.033	-0.38	4.585	-0.021	-0.24	TM
B9EC38		4.634	0.035	0.39	4.614	0.008	0.09	MS
BCEHLJ	X	0.120	-4.480	-50.74	0.121	-4.485	-51.37	MT
CBYXUK		4.582	-0.017	-0.20	4.594	-0.012	-0.14	LA
CG77DB		4.504	-0.095	-1.08	4.513	-0.093	-1.06	FR
DVH4VF		4.522	-0.077	-0.88	4.494	-0.112	-1.28	PP
EAXKLJ		4.653	0.054	0.61	4.659	0.053	0.61	PP
EVYFDL		4.554	-0.045	-0.51	4.548	-0.058	-0.67	TA
EZRK66		4.400	-0.199	-2.26	4.440	-0.166	-1.90	TM
FGA3CV		4.512	-0.087	-0.99	4.528	-0.078	-0.89	PP
FLNTKC		4.589	-0.010	-0.12	4.622	0.016	0.18	EM
G42GMB	X	4.346	-0.253	-2.87	4.410	-0.196	-2.25	TA
G48UB8	*	4.617	0.018	0.20	4.683	0.077	0.88	EM
GRQ6DM		4.703	0.104	1.18	4.696	0.090	1.03	TM
H7Q9CM		4.581	-0.018	-0.21	4.584	-0.022	-0.25	TA
HRNR97		4.629	0.030	0.34	4.617	0.011	0.12	XX
JAJKT6		4.393	-0.207	-2.34	4.413	-0.194	-2.22	TM
JFA23A		4.541	-0.058	-0.66	4.537	-0.069	-0.79	LA
JM8QLY		4.517	-0.082	-0.93	4.511	-0.095	-1.09	PP
JN3EY3		4.730	0.131	1.48	4.710	0.104	1.19	EM
JTUG79		4.673	0.074	0.84	4.677	0.071	0.81	EM
K2N2R2		4.508	-0.091	-1.04	4.476	-0.130	-1.49	LW
KBQLR9		4.440	-0.159	-1.80	4.450	-0.156	-1.79	LW
KMZ78U		4.560	-0.039	-0.44	4.560	-0.046	-0.53	TM
KU4AWT		4.646	0.046	0.53	4.689	0.083	0.95	XX
L9GV36		4.645	0.046	0.52	4.620	0.014	0.16	TA
LAUANT		4.639	0.039	0.45	4.649	0.043	0.49	TM



Paper & Paperboard Interlaboratory Testing Program
Analysis 360
Thickness (Caliper), Printing papers
TAPPI Official Test Method T411

Report #3022G,
October 2019

WebCode	Data Flag	Sample GV71			Sample GV72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
LEQ2U4		4.502	-0.097	-1.10	4.485	-0.121	-1.38	LW
MEZJBE		4.579	-0.021	-0.24	4.601	-0.005	-0.06	LW
NK7J3W		4.644	0.045	0.51	4.683	0.077	0.88	LW
PHFREW		4.717	0.118	1.34	4.732	0.126	1.44	LW
PWFC3		4.573	-0.026	-0.30	4.623	0.017	0.19	XX
Q6KXGU		4.622	0.022	0.25	4.637	0.031	0.35	LW
Q88HHR	*	4.828	0.229	2.59	4.832	0.226	2.59	LW
QAU49T		4.693	0.094	1.06	4.664	0.058	0.66	LW
QYDCPQ		4.482	-0.117	-1.33	4.484	-0.122	-1.40	EM
RPQH82		4.627	0.028	0.31	4.633	0.027	0.31	EM
TFVY7Y	X	4,488.000	4,483.401	50,785.80	4,500.000	4,495.394	51,486.04	TM
TVQCNZ		4.545	-0.054	-0.61	4.576	-0.030	-0.34	PP
UNMTYA		4.577	-0.023	-0.25	4.594	-0.012	-0.14	LW
VGJATW		4.640	0.041	0.46	4.650	0.044	0.50	XX
VWDP4N		4.681	0.082	0.93	4.701	0.095	1.09	TA
W3GWG7		4.545	-0.054	-0.62	4.547	-0.059	-0.68	TM
WMLJZP		4.506	-0.093	-1.06	4.524	-0.082	-0.94	EM
WNWEN3		4.719	0.120	1.36	4.744	0.138	1.58	XX
XYAXJH		4.525	-0.074	-0.84	4.532	-0.074	-0.85	TA
ZLWGKC		4.663	0.064	0.73	4.639	0.033	0.38	LW

Summary Statistics	Sample GV71	Sample GV72
Grand Means	4.60 mils	4.61 mils
Std Dev Btwn Labs	0.09 mils	0.09 mils
Statistics based on 58 of 61 reporting participants.		

Comments on Assigned Data Flags for Test #360

G42GMB (X) - Data for sample GV71 are low.

TFVY7Y (X) - Extreme Data.

BCEHLJ (X) - Extreme Data.

Analysis Notes:

BCEHLJ - Data appear to be reported as micrometers, not mils as indicated on data entry form.

TFVY7Y - Data appear to be reported as mils, not inches as indicated on data entry form.



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 360 Thickness (Caliper), Printing papers TAPPI Official Test Method T411

Key to Instrument Codes Reported by Participants

EM	Emveco	FR	Frank Instruments
LA	L & W Autoline	LW	L & W
MS	Messmer	MT	Mitutoyo
PP	Technidyne Profile/Plus	TA	Thwing-Albert
TM	TMI	XX	Instrument make/model not specified by lab




Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 360 Thickness (Caliper), Printing papers TAPPI Official Test Method T411

Grand Mean Sample GV71 = 4.5993
mils

Grand Mean Sample GV72 = 4.6061
mils





Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 361

Thickness (Caliper), Packaging papers

TAPPI Official Test Method T411

WebCode	Data Flag	Sample GY71			Sample GY72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2HBEVH		14.28	0.14	0.80	14.36	0.21	1.24	LA
3YZPDE		13.96	-0.18	-1.04	14.02	-0.13	-0.76	TA
4FG9PC		14.13	-0.02	-0.10	14.22	0.07	0.42	LW
6UG9ZR	*	14.14	0.00	-0.01	13.95	-0.20	-1.19	LW
6ZYUPP		14.01	-0.13	-0.75	14.09	-0.06	-0.33	EM
7BJBAJ		14.13	-0.01	-0.07	14.11	-0.04	-0.23	LW
7FAVYK		14.28	0.14	0.80	14.33	0.18	1.06	LW
8AGZT8		14.22	0.08	0.43	14.26	0.11	0.63	EM
8WFJPQ	*	14.60	0.46	2.61	14.58	0.43	2.52	EM
92LGR4		14.06	-0.08	-0.46	14.15	0.00	0.03	TM
ARBF73		14.05	-0.09	-0.54	14.04	-0.11	-0.66	LW
EZRK66		13.81	-0.33	-1.90	13.78	-0.37	-2.18	TM
F446AG		13.90	-0.24	-1.38	13.96	-0.19	-1.12	TM
FAVA4K		14.02	-0.13	-0.73	14.00	-0.15	-0.91	TA
G3PZ8C		14.08	-0.06	-0.36	13.99	-0.16	-0.94	TM
G42GMB		13.88	-0.26	-1.50	14.00	-0.15	-0.87	TA
G6UMQ9		14.24	0.10	0.58	14.39	0.24	1.40	TM
H7Q9CM		14.26	0.11	0.65	14.17	0.02	0.14	TA
JGGGC2		14.04	-0.10	-0.58	14.04	-0.11	-0.62	LA
KPUK3Z		14.15	0.01	0.06	14.15	0.00	-0.01	LW
L9GV36		14.24	0.10	0.57	14.15	0.00	-0.01	TA
LZ4PHU		14.05	-0.09	-0.52	14.03	-0.12	-0.68	TM
NGAQD8		14.04	-0.10	-0.59	14.07	-0.08	-0.47	EM
PWA2DW		14.19	0.05	0.27	14.13	-0.02	-0.11	EM
Q3ZYFR		14.09	-0.05	-0.28	14.23	0.08	0.47	LW
RGBWXX		14.31	0.16	0.94	14.31	0.16	0.98	LA
TBGGNG		14.30	0.15	0.87	14.28	0.13	0.79	TM
TMV8VY		14.20	0.06	0.34	14.09	-0.06	-0.38	VP
UQQKT9		14.32	0.18	1.01	14.27	0.12	0.70	TM
V2MVVN		14.14	-0.01	-0.04	14.17	0.02	0.15	TM
VQMFR6		13.89	-0.26	-1.47	13.98	-0.17	-1.00	TA
WNWEN3		14.40	0.26	1.49	14.35	0.20	1.17	LA
YBND3W		14.48	0.34	1.93	14.46	0.31	1.83	EM
YMF4JU		13.96	-0.18	-1.04	13.97	-0.18	-1.05	LW

Summary Statistics	Sample GY71	Sample GY72
Grand Means	14.14 mils	14.15 mils
Std Dev Btwn Labs	0.18 mils	0.17 mils
Statistics based on 34 of 34 reporting participants.		



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 361

Thickness (Caliper), Packaging papers

TAPPI Official Test Method T411

Key to Instrument Codes Reported by Participants

EM	Emveco	LA	L & W Autoline
LW	L & W	TA	Thwing-Albert
TM	TMI	VP	Valmet Paper Lab




Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 361 Thickness (Caliper), Packaging papers TAPPI Official Test Method T411

Grand Mean Sample GY71 = 14.143
mils

Grand Mean Sample GY72 = 14.149
mils





Paper & Paperboard Interlaboratory Testing Program
Analysis 364
Coefficient of Static Friction - Horizontal Plane Method - Printing Papers
TAPPI Official Test Method T549

Report #3022G,
October 2019

WebCode	Data Flag	<u>Sample GD71</u>			<u>Sample GD72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
7FAVYK		0.6248	0.0305	0.37	0.6394	0.0473	0.88	TL
8X7KTT		0.6824	0.0881	1.08	0.5772	-0.0149	-0.28	TA
FLNTKC		0.6032	0.0089	0.11	0.6166	0.0245	0.46	TA
G48UB8		0.6940	0.0997	1.22	0.6700	0.0779	1.45	TA
JN3EY3		0.4980	-0.0963	-1.18	0.5220	-0.0701	-1.31	TA
KMZ78U		0.4880	-0.1063	-1.30	0.5362	-0.0559	-1.04	XX
KT8PAU		0.5694	-0.0249	-0.30	0.5832	-0.0089	-0.17	IT

Summary Statistics	<u>Sample GD71</u>	<u>Sample GD72</u>
Grand Means	0.59 COF	0.59 COF
Std Dev Btwn Labs	0.08 COF	0.05 COF

Statistics based on 7 of 7 reporting participants.

Key to Instrument Codes Reported by Participants

IT	IMASS SP-2100	TA	Thwing-Albert Friction Tester
TL	TMI 32-90 Lab Master/Slip and Friction	XX	Instrument make/model not specified by lab




Paper & Paperboard Interlaboratory Testing Program
Analysis 364
Coefficient of Static Friction - Horizontal Plane Method - Printing Papers
TAPPI Official Test Method T549

Report #3022G,
October 2019

Grand Mean Sample GD71 = 0.59426
COF

Grand Mean Sample GD72 =
0.59209 COF



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 365
Coefficient of Kinetic Friction - Horizontal Plane Method - Printing Papers
TAPPI Official Test Method T549

Report #3022G,
October 2019

WebCode	Data Flag	<u>Sample GD71</u>			<u>Sample GD72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
8X7KTT		0.4694	0.0035	0.08	0.4566	-0.0179	-0.41	TA
AQFRRD		0.5212	0.0553	1.31	0.5228	0.0483	1.10	TA
JM8QLY		0.4674	0.0015	0.03	0.4792	0.0047	0.11	TA
KMZ78U		0.4690	0.0031	0.07	0.4866	0.0121	0.28	XX
KT8PAU		0.3906	-0.0753	-1.79	0.3978	-0.0767	-1.75	IR
QYDCPQ		0.4780	0.0121	0.29	0.5040	0.0295	0.67	TA

Summary Statistics	<u>Sample GD71</u>	<u>Sample GD72</u>
Grand Means	0.47 COF	0.47 COF
Stnd Dev Btwn Labs	0.04 COF	0.04 COF

Statistics based on 6 of 6 reporting participants.

Key to Instrument Codes Reported by Participants

- IR IMASS SP-2000
- TA Thwing-Albert Friction Tester
- XX Instrument make/model not specified by lab




Paper & Paperboard Interlaboratory Testing Program
Analysis 365
Coefficient of Kinetic Friction - Horizontal Plane Method - Printing Papers
TAPPI Official Test Method T549

Report #3022G,
October 2019

Grand Mean Sample GD71 = 0.46593
COF

Grand Mean Sample GD72 =
0.47450 COF



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program

**Report #3022G,
October 2019**

Analysis 370

Air Resistance - Gurley Oil Type

TAPPI Official Test Method T460

WebCode	Data Flag	Sample GE71			Sample GE72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
28BQYE		28.42	2.31	1.87	31.21	2.51	1.83	XX
2F6WTF		25.59	-0.52	-0.42	28.48	-0.22	-0.16	HG
2HBEVH		27.29	1.18	0.95	29.66	0.96	0.70	LA
2ZVZGU		25.22	-0.89	-0.72	28.76	0.06	0.04	LA
38UPYX		26.15	0.04	0.03	28.31	-0.40	-0.29	PP
4AUDQT		24.91	-1.20	-0.97	27.93	-0.77	-0.56	PR
4FG9PC		26.29	0.18	0.15	28.85	0.15	0.11	PP
4GRACB		26.71	0.60	0.49	30.25	1.55	1.13	GL
6UG9ZR		24.95	-1.16	-0.93	26.60	-2.10	-1.53	LP
8X7KTT		27.72	1.61	1.30	29.62	0.92	0.67	WG
99LY7F		25.68	-0.43	-0.34	29.30	0.60	0.44	LP
9GF4XV		27.24	1.13	0.91	28.96	0.26	0.19	PP
ARBE4H		27.59	1.48	1.20	30.78	2.08	1.52	PP
CBYXUK		28.29	2.18	1.76	31.53	2.83	2.07	LA
DVH4VF		26.30	0.19	0.16	28.08	-0.62	-0.45	HG
F446AG		26.53	0.42	0.34	28.90	0.20	0.15	TL
FGA3CV		25.96	-0.14	-0.12	26.88	-1.82	-1.33	HG
G48UB8		26.38	0.27	0.22	28.65	-0.05	-0.04	PP
H7Q9CM	X	29.43	3.32	2.68	28.80	0.10	0.07	PP
JN3EY3		25.47	-0.64	-0.52	29.22	0.52	0.38	PP
JTUG79		27.53	1.42	1.15	28.52	-0.19	-0.14	PP
K2N2R2		25.20	-0.91	-0.73	29.90	1.20	0.87	LW
KMZ78U		24.70	-1.41	-1.14	26.90	-1.80	-1.31	GS
KPUK3Z		26.43	0.32	0.26	28.97	0.27	0.20	LW
L9GV36		27.15	1.04	0.84	30.36	1.66	1.21	GA
NK7J3W		26.03	-0.08	-0.06	27.46	-1.24	-0.90	LP
PWA2DW		26.39	0.29	0.23	29.17	0.47	0.34	PP
Q88HHR		25.74	-0.37	-0.30	29.08	0.38	0.28	PP
QAU49T		25.13	-0.98	-0.79	26.53	-2.17	-1.58	LP
RNFQ3R		27.99	1.88	1.52	29.77	1.07	0.78	LP
RPQH82		24.62	-1.49	-1.20	27.49	-1.21	-0.88	PP
TMV8VY		23.50	-2.61	-2.10	27.89	-0.81	-0.59	VM
TTKRWU		26.32	0.21	0.17	28.00	-0.70	-0.51	XX
TVQCNZ		27.87	1.76	1.42	30.06	1.36	0.99	PP
VEHZ8V		23.83	-2.28	-1.84	26.55	-2.15	-1.57	LP
VGJATW		24.33	-1.78	-1.43	26.56	-2.14	-1.56	XX
WMLJZP		26.87	0.76	0.62	29.88	1.18	0.86	HG
XDQX8W		25.96	-0.15	-0.12	30.35	1.65	1.20	XX
XUDDBT		26.46	0.35	0.28	27.38	-1.32	-0.96	PP
XYAXJH		25.70	-0.41	-0.33	29.00	0.30	0.22	PP
YMF4JU		23.86	-2.25	-1.82	26.27	-2.44	-1.78	TL



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 370

Air Resistance - Gurley Oil Type

TAPPI Official Test Method T460

Summary Statistics	Sample GE71	Sample GE72
Grand Means	26.11 sec/100 cc	28.70 sec/100 cc
Stnd Dev Btwn Labs	1.24 sec/100 cc	1.37 sec/100 cc

Statistics based on 40 of 41 reporting participants.

Comments on Assigned Data Flags for Test #370

H7Q9CM (X) - Inconsistent in testing between samples.

Key to Instrument Codes Reported by Participants

GA Gurley Precision #4340 Automatic Densometer	GL Gurley #4110
GS Gurley-Hill S-P-S Tester #4190	HG Technidyne - Hagerty Model #1
LA L & W Autoline	LP L & W Densometer, Air Permeance
LW L & W Type Gurley Densometer, Oil Flotation	PP Technidyne Profile/Plus
PR Parker Print-Surf (PPS) Model M590	TL Gurley Densometer #4110, Oil Flotation
VM Valmet PaperLab (was Kajaani/Robotest)	WG W & LE Gurley Tester
XX Instrument make/model not specified by lab	



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 370


Air Resistance - Gurley Oil Type

TAPPI Official Test Method T460

Grand Mean Sample GE71 = 26.107
sec/100 cc

Grand Mean Sample GE72 = 28.701
sec/100 cc

ANALYSIS 370





Paper & Paperboard Interlaboratory Testing Program
Analysis 372
Porosity - Sheffield Type - Sheffield Units for 3/4 inch Diameter Orifice
TAPPI Official Test Method T547

Report #3022G,
October 2019

WebCode	Data Flag	Sample GE71			Sample GE72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
78WNJG		93.4	-16.6	-1.73	86.8	-15.9	-2.30	GA
HRNR97		119.9	9.9	1.04	103.9	1.2	0.17	LA
KMZ78U		117.7	7.7	0.81	106.6	3.9	0.57	SH
L9GV36		99.3	-10.6	-1.11	97.0	-5.7	-0.83	GA
LAUANT		110.5	0.5	0.06	109.0	6.3	0.91	TT
MCFEXB		123.4	13.4	1.40	107.4	4.7	0.68	LP
TFVY7Y		105.3	-4.7	-0.49	102.4	-0.3	-0.04	TT
TMV8VY		116.8	6.8	0.71	110.4	7.7	1.11	PP
VWDP4N		104.4	-5.6	-0.58	100.1	-2.6	-0.38	HM
XYAXJH		109.0	-1.0	-0.10	103.4	0.7	0.10	PP

Summary Statistics	Sample GE71	Sample GE72
Grand Means	109.97 Sheffield Units	102.69 Sheffield Units
Std Dev Btwn Labs	9.58 Sheffield Units	6.91 Sheffield Units
Statistics based on 10 of 10 reporting participants.		

Key to Instrument Codes Reported by Participants

GA Gurley Precision #4340 Automatic Densometer	HM Technidyne - Hagerty Model #538
LA L & W Roughness Sheffield - Autoline	LP L & W Densometer, Air Permeance
PP Technidyne Profile/Plus	SH Sheffield
TT TMI Monitor/Smoothness II, Model 58-24	




Paper & Paperboard Interlaboratory Testing Program
Analysis 372
Porosity - Sheffield Type - Sheffield Units for 3/4 inch Diameter Orifice
TAPPI Official Test Method T547

Report #3022G,
October 2019

Grand Mean Sample GE71 = 109.97
Sheffield Units

Grand Mean Sample GE72 = 102.69
Sheffield Units



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 376
Roughness - Print Surf Method - 0.5 to 4.0 Microns
TAPPI Official Test Method T555

Report #3022G,
October 2019

WebCode	Data Flag	Sample GJ71			Sample GJ72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
6ZYUPP		0.8090	-0.0364	-0.46	0.8110	-0.0456	-0.56	ZZ
7BJBAJ		0.8950	0.0496	0.63	0.8850	0.0284	0.35	ZZ
8DG7CJ		0.7780	-0.0674	-0.85	0.7870	-0.0696	-0.85	ZZ
8WFJPQ		0.8530	0.0076	0.10	0.8700	0.0134	0.16	ZZ
8X7KTT		0.7650	-0.0804	-1.02	0.7690	-0.0876	-1.08	ZZ
AQFRRD		0.8210	-0.0244	-0.31	0.7840	-0.0726	-0.89	ZZ
ARBF73		0.8030	-0.0424	-0.54	0.8380	-0.0186	-0.23	ZZ
AVCHXP	X	1.3780	0.5326	6.73	1.3680	0.5114	6.28	ZZ
AYDQZE		0.9060	0.0606	0.77	0.8760	0.0194	0.24	ZZ
DVH4VF		0.8180	-0.0274	-0.35	0.8480	-0.0086	-0.11	ZZ
EAXKLJ		0.8150	-0.0304	-0.38	0.7790	-0.0776	-0.95	ZZ
H7Q9CM		1.0010	0.1556	1.97	1.0230	0.1664	2.04	ZZ
JN3EY3		0.8340	-0.0114	-0.14	0.8460	-0.0106	-0.13	ZZ
JTUG79		0.8720	0.0266	0.34	0.9000	0.0434	0.53	ZZ
K2MBGC	X	119.8000	118.9546	1,503.17	124.8000	123.9434	1,521.07	ZZ
LXDMD7		0.8710	0.0256	0.32	0.9650	0.1084	1.33	ZZ
NGAQD8		0.8050	-0.0404	-0.51	0.8220	-0.0346	-0.43	ZZ
PHFREW		0.8140	-0.0314	-0.40	0.8590	0.0024	0.03	ZZ
RGBWXX		0.9560	0.1106	1.40	1.0040	0.1474	1.81	ZZ
RPQH82		0.8110	-0.0344	-0.44	0.7480	-0.1086	-1.33	ZZ
TFVY7Y	*	1.0550	0.2096	2.65	0.9260	0.0694	0.85	ZZ
TMV8VY		0.7830	-0.0624	-0.79	0.7820	-0.0746	-0.92	ZZ
WDHJ93		0.7510	-0.0944	-1.19	0.6960	-0.1606	-1.97	ZZ
WNWEN3		0.9640	0.1186	1.50	0.9490	0.0924	1.13	ZZ
XYAXJH		0.8270	-0.0184	-0.23	0.8160	-0.0406	-0.50	ZZ
YBND3W		0.7940	-0.0514	-0.65	0.8850	0.0284	0.35	ZZ
ZUAN6L	*	0.7350	-0.1104	-1.40	0.9480	0.0914	1.12	ZZ

Summary Statistics	Sample GJ71	Sample GJ72
Grand Means	0.85 Microns	0.86 Microns
Std Dev Btwn Labs	0.08 Microns	0.08 Microns

Statistics based on 25 of 27 reporting participants.

Comments on Assigned Data Flags for Test #376

- AVCHXP (X) - Extreme Data.
- K2MBGC (X) - Extreme Data.



Paper & Paperboard Interlaboratory Testing Program

**Report #3022G,
October 2019**

Analysis 376

Roughness - Print Surf Method - 0.5 to 4.0 Microns

TAPPI Official Test Method T555

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019


Analysis 376

Roughness - Print Surf Method - 0.5 to 4.0 Microns

TAPPI Official Test Method T555

Grand Mean Sample GJ71 = 0.84544
Microns

Grand Mean Sample GJ72 =
0.85664 Microns





Paper & Paperboard Interlaboratory Testing Program
Analysis 377
Roughness - Print Surf Method - 2.5 to 6.0 Microns
TAPPI Official Test Method T555

Report #3022G,
October 2019

WebCode	Data Flag	<u>Sample GK71</u>			<u>Sample GK72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2ZVZGU		3.362	-0.335	-1.35	3.723	-0.350	-1.52	ZZ
4FG9PC		3.611	-0.086	-0.34	3.935	-0.138	-0.60	ZZ
7FAVYK		3.648	-0.049	-0.20	3.998	-0.075	-0.33	ZZ
8WFJPQ		4.068	0.371	1.49	4.334	0.261	1.13	ZZ
8X7KTT		3.425	-0.272	-1.09	3.841	-0.232	-1.00	ZZ
FLNTKC		3.624	-0.073	-0.29	4.132	0.059	0.25	ZZ
G48UB8		3.687	-0.010	-0.04	4.076	0.003	0.01	ZZ
PWA2DW		4.087	0.390	1.57	4.455	0.382	1.65	ZZ
WNWEN3		3.759	0.062	0.25	4.164	0.091	0.39	ZZ

Summary Statistics	<u>Sample GK71</u>	<u>Sample GK72</u>
Grand Means	3.70 Microns	4.07 Microns
Std Dev Btwn Labs	0.25 Microns	0.23 Microns
Statistics based on 9 of 9 reporting participants.		

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019


Analysis 377

Roughness - Print Surf Method - 2.5 to 6.0 Microns

TAPPI Official Test Method T555

Grand Mean Sample GK71 = 3.6968
Microns

Grand Mean Sample GK72 = 4.0731
Microns



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 378
Roughness - Sheffield Type
TAPPI Official Test Method T538

Report #3022G,
October 2019

WebCode	Data Flag	Sample GL71			Sample GL72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		119.1	1.5	0.21	116.8	-1.7	-0.24	TS
2ZVZGU		119.9	2.3	0.33	122.4	3.9	0.55	LA
38UPYX		110.0	-7.6	-1.05	108.5	-10.0	-1.41	SH
4FG9PC		115.2	-2.3	-0.32	122.3	3.8	0.54	PP
4J3UFD		111.7	-5.8	-0.81	110.0	-8.5	-1.21	MP
638U7P		116.8	-0.7	-0.10	120.3	1.8	0.26	PP
6ZYUUP		117.4	-0.2	-0.02	123.4	4.9	0.69	PP
78WNJG		122.5	4.9	0.69	124.1	5.6	0.79	GA
7BJBAJ		120.1	2.5	0.35	121.1	2.6	0.37	PP
7QCZ9M		113.0	-4.6	-0.63	115.0	-3.5	-0.50	PP
8WFJPQ		120.4	2.8	0.39	121.1	2.6	0.37	LW
8X7KTT		126.2	8.6	1.20	131.2	12.7	1.79	XX
9GF4XV		115.3	-2.2	-0.31	115.7	-2.8	-0.40	PP
AQFRRD		122.8	5.2	0.73	124.9	6.4	0.90	HM
ARBE4H		119.5	1.9	0.27	116.0	-2.6	-0.36	PP
CBYXUK		100.9	-16.7	-2.31	105.0	-13.5	-1.91	LA
D2NV9K		114.8	-2.8	-0.38	119.8	1.3	0.18	LA
DVH4VF		110.4	-7.2	-0.99	116.9	-1.6	-0.23	HM
EZRK66	*	136.0	18.4	2.56	132.5	14.0	1.98	GL
FAVA4K		106.1	-11.5	-1.59	108.4	-10.1	-1.43	PP
FGA3CV		115.2	-2.4	-0.33	109.6	-8.9	-1.26	HM
FLNTKC		110.0	-7.6	-1.05	115.4	-3.1	-0.44	PP
G48UB8		110.8	-6.7	-0.93	116.1	-2.4	-0.35	PP
HRNR97		117.6	0.0	0.01	113.6	-4.9	-0.69	LA
JFA23A		124.5	6.9	0.96	125.2	6.7	0.95	LA
JN3EY3		110.7	-6.9	-0.95	111.8	-6.7	-0.95	PP
JPUDC2		114.9	-2.7	-0.37	117.3	-1.2	-0.17	GA
JTUG79		109.8	-7.7	-1.07	113.6	-4.9	-0.70	PP
K2MBGC		119.8	2.2	0.31	124.8	6.3	0.89	LW
K2N2R2		122.8	5.2	0.73	124.5	6.0	0.85	TS
KMZ78U		114.4	-3.2	-0.44	114.6	-3.9	-0.55	XX
L9GV36		115.7	-1.9	-0.26	117.9	-0.6	-0.09	PP
LAUANT	*	137.5	19.9	2.77	137.0	18.5	2.61	TT
MCFEXB	*	122.8	5.2	0.73	112.9	-5.6	-0.79	LW
NGAQD8		109.9	-7.6	-1.06	110.7	-7.8	-1.10	PP
PWA2DW		121.4	3.8	0.53	120.5	2.0	0.28	LW
PWFA3		125.5	7.9	1.10	129.5	11.0	1.55	XX
Q88HHR		106.1	-11.4	-1.58	105.6	-12.9	-1.83	PP
QZTGGW		110.3	-7.3	-1.01	112.6	-5.9	-0.84	TT
RGBWXX		120.1	2.5	0.35	126.2	7.7	1.09	LA
RJGCF3		124.2	6.6	0.92	122.7	4.2	0.59	XX



Paper & Paperboard Interlaboratory Testing Program
Analysis 378
Roughness - Sheffield Type
TAPPI Official Test Method T538

Report #3022G,
October 2019

WebCode	Data Flag	Sample GL71			Sample GL72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
RNFQ3R		111.2	-6.4	-0.88	109.5	-9.0	-1.27	LW
TFVY7Y		121.0	3.4	0.48	120.7	2.2	0.31	TT
TMV8VY		114.9	-2.7	-0.37	111.8	-6.7	-0.95	VM
TVQCNZ		120.1	2.5	0.35	122.8	4.3	0.61	PP
UQQKT9	*	137.7	20.2	2.80	132.6	14.0	1.99	GA
VGJATW		116.5	-1.1	-0.15	114.4	-4.1	-0.58	XX
VQMFR6		114.1	-3.5	-0.48	114.7	-3.8	-0.53	PP
WMLJZP		115.7	-1.9	-0.26	112.7	-5.8	-0.82	HM
WNWEN3		121.6	4.0	0.56	123.1	4.6	0.65	LA
XUDDBT		118.3	0.7	0.10	119.6	1.1	0.15	PP
XYAXJH		117.9	0.3	0.05	119.3	0.8	0.11	PP
YBND3W		119.1	1.6	0.22	122.5	4.0	0.56	PP

Summary Statistics	Sample GL71	Sample GL72
Grand Means	117.55 Sheffield	118.51 Sheffield
Std Dev Btwn Labs	7.21 Sheffield	7.08 Sheffield

Statistics based on 53 of 53 reporting participants.

Key to Instrument Codes Reported by Participants

GA Gurley Precision #4340 Automatic Densometer	GL Giddings and Lewis Sheffield
HM Technidyne - Hagerty Model #538	LA L & W Roughness Sheffield - Autoline
LW L & W Roughness Tester	MP Metso Paperlab
PP Technidyne Profile/Plus	SH Sheffield (Bendix Precisionaire)
TS TMI Monitor/Smoothness, Model 58-02	TT TMI Monitor/Smoothness II, Model 58-24
VM Valmet PaperLab (was Kajaani\Robotest)	XX Instrument make/model not specified by lab



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 378


Roughness - Sheffield Type

TAPPI Official Test Method T538

Grand Mean Sample GL71 = 117.55
Sheffield

Grand Mean Sample GL72 = 118.51
Sheffield

ANALYSIS 378





Paper & Paperboard Interlaboratory Testing Program
Analysis 382
Moisture in Paper
TAPPI Official Test Method T412

Report #3022G,
October 2019

WebCode	Data Flag	Sample GM71			Sample GM72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
8GGH8J		4.207	-0.285	-0.93	4.157	-0.205	-0.66	ZZ
B9EC38		4.295	-0.197	-0.64	4.240	-0.122	-0.39	ZZ
CWHKWT		4.728	0.236	0.77	4.503	0.141	0.45	ZZ
G48UB8		4.881	0.390	1.27	4.874	0.512	1.64	ZZ
GRTW74		4.281	-0.211	-0.69	4.053	-0.309	-0.99	ZZ
KB9GAA		4.927	0.435	1.42	4.746	0.383	1.23	ZZ
KU4AWT		4.520	0.029	0.09	4.410	0.047	0.15	ZZ
QAU49T		4.106	-0.386	-1.26	4.018	-0.344	-1.10	ZZ
QGD349		4.900	0.408	1.34	4.870	0.508	1.63	ZZ
R6J976		4.431	-0.061	-0.20	4.377	0.014	0.05	ZZ
V2MVVN		4.074	-0.418	-1.37	3.939	-0.423	-1.36	ZZ
ZLWGKC		4.341	-0.150	-0.49	4.195	-0.167	-0.54	ZZ
ZZHWNC		4.700	0.208	0.68	4.330	-0.032	-0.10	ZZ

Summary Statistics	Sample GM71	Sample GM72
Grand Means	4.49 Percent	4.36 Percent
Std Dev Btwn Labs	0.31 Percent	0.31 Percent

Statistics based on 13 of 13 reporting participants.

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked



Paper & Paperboard Interlaboratory Testing Program


Report #3022G,
October 2019

Analysis 382 Moisture in Paper

TAPPI Official Test Method T412

Grand Mean Sample GM71 = 4.4916
Percent

Grand Mean Sample GM72 = 4.3624
Percent



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program

**Report #3022G,
October 2019**

Analysis 384

Opacity (89% Reflectance Backing) - Fine Papers

TAPPI Official Test Method T425

WebCode	Data Flag	Sample GN71			Sample GN72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF	X	95.51	-0.71	-1.87	96.06	-0.17	-0.47	ZZ
2ZVZGU		95.86	-0.36	-0.95	96.14	-0.09	-0.26	ZZ
38UPYX		95.99	-0.23	-0.61	96.05	-0.18	-0.50	ZZ
4AUDQT		96.19	-0.04	-0.10	96.39	0.16	0.43	ZZ
4FG9PC		95.92	-0.31	-0.81	95.82	-0.41	-1.12	ZZ
638U7P		96.34	0.12	0.31	96.35	0.12	0.33	ZZ
7QCZ9M		96.14	-0.08	-0.22	96.19	-0.04	-0.12	ZZ
8DG7CJ		96.16	-0.06	-0.17	96.02	-0.21	-0.58	ZZ
9GF4XV		96.04	-0.19	-0.49	95.96	-0.27	-0.73	ZZ
AQFRRD		96.42	0.20	0.51	96.47	0.24	0.64	ZZ
AVCHXP	*	97.41	1.18	3.09	97.29	1.06	2.87	ZZ
AYDQZE		96.19	-0.03	-0.08	96.23	0.00	-0.01	ZZ
CBYXUK	X	92.12	-4.10	-10.73	92.05	-4.18	-11.34	ZZ
DVH4VF		96.19	-0.03	-0.09	96.12	-0.11	-0.31	ZZ
ECNLPL		96.61	0.39	1.01	96.48	0.24	0.66	ZZ
EZRK66	X	99.87	3.65	9.54	99.75	3.52	9.53	ZZ
FLNTKC		96.02	-0.21	-0.54	96.04	-0.19	-0.52	ZZ
G48UB8		96.63	0.40	1.06	96.68	0.45	1.22	ZZ
G6UMQ9		95.82	-0.41	-1.06	95.73	-0.50	-1.35	ZZ
GRQ6DM		96.30	0.08	0.20	96.30	0.07	0.18	ZZ
H7Q9CM	*	96.22	-0.01	-0.02	96.58	0.35	0.95	ZZ
HRNR97		95.93	-0.29	-0.77	95.98	-0.25	-0.69	ZZ
JN3EY3		96.68	0.46	1.19	96.63	0.39	1.06	ZZ
K2N2R2		96.25	0.03	0.07	96.16	-0.07	-0.20	ZZ
KMZ78U	X	96.32	0.10	0.25	95.18	-1.05	-2.86	ZZ
L9GV36		95.87	-0.35	-0.93	95.97	-0.26	-0.71	ZZ
LAUANT		95.78	-0.44	-1.16	95.75	-0.48	-1.31	ZZ
PWFA3		96.24	0.01	0.03	96.22	-0.01	-0.03	ZZ
Q88HHR		96.44	0.22	0.57	96.37	0.14	0.37	ZZ
RPQH82		96.00	-0.22	-0.59	96.19	-0.04	-0.12	ZZ
TFVY7Y		96.23	0.01	0.02	96.26	0.03	0.07	ZZ
TVQCNZ		95.93	-0.29	-0.77	95.79	-0.44	-1.20	ZZ
VGJATW	*	97.35	1.13	2.96	97.27	1.03	2.80	ZZ
WMLJZP		95.95	-0.27	-0.72	95.91	-0.32	-0.88	ZZ
XYAXJH		96.12	-0.10	-0.27	96.09	-0.14	-0.39	ZZ
ZUAN6L		95.97	-0.25	-0.66	96.03	-0.21	-0.56	ZZ



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 384

Opacity (89% Reflectance Backing) - Fine Papers

TAPPI Official Test Method T425

Summary Statistics	Sample GN71	Sample GN72
Grand Means	96.22 Percent	96.23 Percent
Stnd Dev Btwn Labs	0.38 Percent	0.37 Percent

Statistics based on 32 of 36 reporting participants.

Comments on Assigned Data Flags for Test #384

CBYXUK (X) - Extreme Data.

KMZ78U (X) - Data for sample GN72 are low.

EZRK66 (X) - Extreme Data.

2F6WTF (X) - Inconsistent in testing between samples.

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019


Analysis 384

Opacity (89% Reflectance Backing) - Fine Papers

TAPPI Official Test Method T425

Grand Mean Sample GN71 = 96.224
Percent

Grand Mean Sample GN72 = 96.234
Percent





Paper & Paperboard Interlaboratory Testing Program
Analysis 386
Opacity (Paper Backing) - Fine Papers and Newsprint
TAPPI Official Test Method T519

Report #3022G,
October 2019

WebCode	Data Flag	<u>Sample GP71</u>			<u>Sample GP72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
38TQZJ		93.49	0.11	1.07	93.36	0.02	0.34	ZZ
6UG9ZR		93.49	0.11	1.04	93.38	0.04	0.69	ZZ
8AGZT8		93.21	-0.17	-1.58	93.25	-0.08	-1.37	ZZ
99LY7F		93.31	-0.07	-0.65	93.35	0.02	0.30	ZZ
ARBF73		93.47	0.09	0.83	93.27	-0.06	-0.99	ZZ
B474JH		93.50	0.12	1.14	93.45	0.12	1.93	ZZ
F446AG		93.39	0.01	0.11	93.33	0.00	-0.06	ZZ
KPUK3Z		93.37	0.00	-0.05	93.39	0.05	0.87	ZZ
KU4AWT		93.44	0.06	0.54	93.36	0.03	0.49	ZZ
Q6KXGU		93.30	-0.08	-0.74	93.27	-0.06	-0.98	ZZ
QAU49T		93.35	-0.03	-0.27	93.35	0.02	0.33	ZZ
UNMTYA		93.28	-0.10	-0.90	93.36	0.02	0.39	ZZ
V8FVC6		93.20	-0.18	-1.69	93.33	0.00	-0.05	ZZ
XDQX8W		93.50	0.12	1.14	93.22	-0.11	-1.88	ZZ

Summary Statistics	<u>Sample GP71</u>	<u>Sample GP72</u>
Grand Means	93.38 Percent	93.33 Percent
Std Dev Btwn Labs	0.11 Percent	0.06 Percent

Statistics based on 14 of 14 reporting participants.

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019


Analysis 386

Opacity (Paper Backing) - Fine Papers and Newsprint

TAPPI Official Test Method T519

Grand Mean Sample GP71 = 93.378
Percent

Grand Mean Sample GP72 = 93.334
Percent



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 390
Directional Brightness
TAPPI Official Test Method T452

Report #3022G,
October 2019

WebCode	Data Flag	Sample GR71			Sample GR72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		83.40	-0.77	-0.66	82.49	-0.92	-0.76	TS
2ZVZGU		83.90	-0.28	-0.24	82.89	-0.52	-0.43	TS
638U7P		83.15	-1.02	-0.88	82.39	-1.02	-0.84	TS
6ZYUPP		84.11	-0.06	-0.05	83.40	-0.01	-0.01	HG
7BJBAJ		83.55	-0.62	-0.54	82.54	-0.87	-0.72	PP
7QCZ9M		83.39	-0.79	-0.67	82.35	-1.06	-0.87	XX
8DG7CJ		85.22	1.04	0.90	84.42	1.02	0.84	TS
8WFJPQ		82.00	-2.17	-1.87	81.54	-1.87	-1.55	TT
AQFRRD		83.21	-0.96	-0.83	82.35	-1.06	-0.87	TS
AVCHXP		84.77	0.60	0.52	84.03	0.62	0.51	VM
B9EC38		84.25	0.08	0.07	83.65	0.24	0.20	XX
C6U27E		85.23	1.06	0.91	84.35	0.94	0.78	TS
FAVA4K		83.46	-0.71	-0.61	82.53	-0.88	-0.72	TS
G6UMQ9		85.11	0.94	0.81	84.17	0.77	0.64	TS
JAJKT6		84.50	0.33	0.28	83.76	0.36	0.29	HG
JN3EY3		83.38	-0.80	-0.69	82.80	-0.61	-0.50	TT
K2MBGC	X	86.53	2.35	2.02	86.89	3.49	2.88	HZ
KMZ78U	*	87.36	3.18	2.74	86.70	3.29	2.72	PE
L9GV36		84.62	0.44	0.38	84.08	0.67	0.55	XC
LAUANT		85.66	1.49	1.28	85.35	1.94	1.61	TS
NGAQD8		85.24	1.06	0.91	84.43	1.02	0.84	TT
PWA2DW		85.03	0.86	0.74	84.18	0.77	0.64	HG
PWFA3		84.78	0.61	0.52	84.24	0.84	0.69	XX
Q88HHR		82.94	-1.24	-1.06	82.16	-1.24	-1.03	TT
RPQH82		83.10	-1.07	-0.92	81.96	-1.44	-1.19	TT
TVQCNZ		82.69	-1.49	-1.28	82.19	-1.22	-1.01	TT
VGJATW	X	69.53	-14.64	-12.58	68.12	-15.29	-12.65	XX
VQMFR6		83.22	-0.95	-0.82	82.37	-1.03	-0.86	TS
YBND3W		85.42	1.24	1.07	84.65	1.24	1.03	HG

Summary Statistics	Sample GR71	Sample GR72
Grand Means	84.17 Percent	83.41 Percent
Std Dev Btwn Labs	1.16 Percent	1.21 Percent
Statistics based on 27 of 29 reporting participants.		

Comments on Assigned Data Flags for Test #390

VGJATW (X) - Extreme Data.

K2MBGC (X) - Data for sample GR72 are high.



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 390

Directional Brightness

TAPPI Official Test Method T452

Key to Instrument Codes Reported by Participants

HG	Hunter Labscan / XE	HZ	Hunter Lab ColorFlex EZ Series
PE	Photovolt 577	PP	Technidyne Profile/Plus
TS	Technidyne Brightimeter Micro S-5	TT	Technidyne Brightimeter Micro S4-M
VM	Valmet PaperLab (was Kajaani/Robotest)	XC	X-Rite Color i5
XX	Instrument make/model not specified by lab		




Paper & Paperboard Interlaboratory Testing Program
Analysis 390
Directional Brightness
TAPPI Official Test Method T452

Report #3022G,
October 2019

Grand Mean Sample GR71 = 84.173
Percent

Grand Mean Sample GR72 = 83.406
Percent

ANALYSIS 390





Paper & Paperboard Interlaboratory Testing Program
Analysis 391
Directional Brightness of Fluorescent Samples
TAPPI Official Test Method T452

Report #3022G,
October 2019

WebCode	Data Flag	Sample GZ71			Sample GZ72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		95.18	-0.20	-0.29	95.17	-0.22	-0.34	TS
38UPYX		93.70	-1.69	-2.44	93.76	-1.64	-2.48	HT
4AUDQT		96.45	1.06	1.53	96.45	1.05	1.60	TS
4FG9PC		95.74	0.35	0.51	95.82	0.43	0.65	TS
AYDQZE		95.42	0.03	0.04	95.42	0.03	0.04	TS
CBYXUK		95.12	-0.27	-0.39	95.20	-0.20	-0.30	TT
DVH4VF		95.75	0.36	0.52	96.24	0.84	1.28	TT
G48UB8		95.07	-0.32	-0.46	95.22	-0.18	-0.27	TS
H7Q9CM		95.21	-0.18	-0.25	94.99	-0.40	-0.61	PP
K2N2R2		95.20	-0.19	-0.27	95.24	-0.16	-0.24	TS
PWFA3		96.14	0.75	1.09	96.13	0.74	1.12	XX
TFVY7Y	*	96.56	1.17	1.69	95.94	0.54	0.83	TT
V8FVC6		95.15	-0.23	-0.34	95.17	-0.22	-0.34	TS
WMLJZP		95.08	-0.31	-0.44	95.08	-0.32	-0.48	HT
ZUAN6L		95.04	-0.35	-0.50	95.09	-0.31	-0.47	PP

Summary Statistics	Sample GZ71	Sample GZ72
Grand Means	95.39 Percent	95.40 Percent
Std Dev Btwn Labs	0.69 Percent	0.66 Percent
Statistics based on 15 of 15 reporting participants.		

Analysis Notes:

DVH4VF - One determination removed from the Lab Mean of Sample GZ71 per Grubb's Test at 1% risk (TAPPI 1205).

Key to Instrument Codes Reported by Participants

HT	Hunter UltraScan Vis	PP	Technidyne Profile/Plus
TS	Technidyne Brightimeter Micro S-5	TT	Technidyne Brightimeter Micro S4-M
XX	Instrument make/model not specified by lab		




Paper & Paperboard Interlaboratory Testing Program
Analysis 391
Directional Brightness of Fluorescent Samples
TAPPI Official Test Method T452

Report #3022G,
October 2019

Grand Mean Sample GZ71 = 95.387
Percent

Grand Mean Sample GZ72 = 95.395
Percent



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program

**Report #3022G,
October 2019**

**Analysis 392
Diffuse Brightness**

TAPPI Official Test Method T525

WebCode	Data Flag	<u>Sample GR71</u>			<u>Sample GR72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2ZVZGU		83.68	0.12	0.31	82.87	0.06	0.28	TC
7BJBAJ		83.95	0.39	1.06	83.17	0.37	1.64	LT
8AGZT8		83.51	-0.05	-0.15	82.60	-0.21	-0.93	LA
8WFJPQ		82.90	-0.66	-1.80	82.68	-0.13	-0.57	EG
99LY7F		83.77	0.21	0.56	82.94	0.13	0.59	TC
AQFRRD		83.38	-0.19	-0.51	82.63	-0.17	-0.77	LT
ARBF73		83.74	0.17	0.47	83.10	0.30	1.33	AC
B474JH		83.73	0.17	0.46	82.79	-0.02	-0.09	TC
B7RPC6		83.04	-0.52	-1.43	82.71	-0.09	-0.41	TZ
B9EC38		83.75	0.19	0.52	82.87	0.07	0.29	EE
C6U27E		83.61	0.05	0.12	82.65	-0.15	-0.69	TC
EAXKLJ		83.62	0.06	0.16	82.67	-0.13	-0.59	TC
F446AG		84.23	0.66	1.81	83.36	0.56	2.51	TM
KBQLR9		82.66	-0.90	-2.46	82.44	-0.37	-1.65	TC
KU4AWT		83.39	-0.17	-0.48	82.57	-0.24	-1.07	EG
LEQ2U4		83.52	-0.04	-0.12	82.68	-0.13	-0.57	TC
NGAQD8		83.94	0.38	1.02	83.10	0.30	1.33	TL
PHFREW		83.94	0.38	1.03	82.88	0.07	0.33	TC
PWA2DW		82.83	-0.74	-2.01	82.53	-0.27	-1.23	TC
QAU49T		83.57	0.01	0.02	82.75	-0.05	-0.25	LE
QYDCPQ		83.59	0.03	0.09	82.80	-0.01	-0.04	TC
RNFQ3R		83.89	0.33	0.90	83.09	0.29	1.29	EF
RUG3W4		83.57	0.00	0.01	82.77	-0.04	-0.16	TC
UNMTYA		83.73	0.17	0.46	82.88	0.07	0.32	LE
V8FVC6		83.53	-0.03	-0.09	82.63	-0.17	-0.78	TC
XUDDBT		83.88	0.31	0.85	83.01	0.21	0.93	TC
XYAXJH		83.26	-0.30	-0.83	82.58	-0.23	-1.03	TC

Summary Statistics	<u>Sample GR71</u>	<u>Sample GR72</u>
Grand Means	83.56 Percent	82.80 Percent
Std Dev Btwn Labs	0.37 Percent	0.22 Percent

Statistics based on 27 of 27 reporting participants.



Key to Instrument Codes Reported by Participants

AC	ACS Spectro-Sensor II	EE	Datacolor Elrepho 2000
EF	Datacolor Elrepho 3000	EG	Datacolor Elrepho 450X
LA	L & W Elrepho - Autoline	LE	L & W Elrepho
LT	L & W Elrepho SE 071	TC	Technidyne Color Touch Series
TL	Technidyne Technibrite TB-1	TM	Technidyne Technibrite Micro TB-1C
TZ	Technibrite Model TB-1		



Paper & Paperboard Interlaboratory Testing Program


Report #3022G,
October 2019

Analysis 392 Diffuse Brightness

TAPPI Official Test Method T525

Grand Mean Sample GR71 = 83.562
Percent

Grand Mean Sample GR72 = 82.805
Percent





Paper & Paperboard Interlaboratory Testing Program
Analysis 394
Fluorescent Component of Directional Brightness
TAPPI Official Test Method T452

Report #3022G,
October 2019

WebCode	Data Flag	<u>Sample GZ71</u>			<u>Sample GZ72</u>			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		8.188	0.256	0.78	8.090	0.156	0.50	TS
4AUDQT		7.880	-0.052	-0.16	7.920	-0.014	-0.05	TS
4FG9PC		8.442	0.510	1.54	8.448	0.514	1.66	TS
AYDQZE		8.076	0.144	0.44	8.070	0.136	0.44	TS
CBYXUK		7.560	-0.372	-1.13	7.600	-0.334	-1.08	TT
DVH4VF		8.140	0.208	0.63	8.160	0.226	0.73	TT
G48UB8		8.104	0.172	0.52	8.080	0.146	0.47	TS
H7Q9CM		7.894	-0.038	-0.12	7.894	-0.040	-0.13	PP
PWFCA3		7.256	-0.676	-2.05	7.308	-0.626	-2.02	XX
V8FVC6		7.682	-0.250	-0.76	7.682	-0.252	-0.82	TS
ZUAN6L		8.030	0.098	0.30	8.022	0.088	0.28	PP

Summary Statistics	<u>Sample GZ71</u>	<u>Sample GZ72</u>
Grand Means	7.93 Percent	7.93 Percent
Std Dev Btwn Labs	0.33 Percent	0.31 Percent
Statistics based on 11 of 11 reporting participants.		

Key to Instrument Codes Reported by Participants

PP	Technidyne Profile/Plus	TS	Technidyne Brightimeter Micro S-5
TT	Technidyne Brightimeter Micro S4-M	XX	Instrument make/model not specified by lab




Paper & Paperboard Interlaboratory Testing Program
Analysis 394
Fluorescent Component of Directional Brightness
TAPPI Official Test Method T452

Report #3022G,
October 2019

Grand Mean Sample GZ71 = 7.9320
Percent

Grand Mean Sample GZ72 = 7.9340
Percent



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 395
Specular Gloss at 75 Degrees - High Range
TAPPI Official Test Method T480

Report #3022G,
October 2019

WebCode	Data Flag	Sample GT71			Sample GT72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
6ZYUPP		82.44	4.08	2.12	83.61	5.39	2.04	TH
7BJBAJ		77.23	-1.13	-0.59	77.30	-0.92	-0.35	GA
8DG7CJ		75.72	-2.64	-1.37	76.04	-2.18	-0.83	LA
8WFJPQ		79.32	0.96	0.50	78.69	0.47	0.18	TH
ARBF73		77.66	-0.70	-0.37	77.79	-0.43	-0.16	LB
AVCHXP		79.23	0.87	0.45	79.21	0.99	0.38	VM
AYDQZE		78.23	-0.13	-0.07	78.29	0.07	0.03	LA
DVH4VF		75.07	-3.29	-1.71	74.97	-3.25	-1.23	PP
H7Q9CM		79.14	0.78	0.40	79.60	1.38	0.52	PP
NGAQD8		77.55	-0.81	-0.42	77.86	-0.36	-0.14	GM
RGBWXX	*	77.38	-0.98	-0.51	72.51	-5.71	-2.16	LF
RPQH82	X	66.08	-12.28	-6.38	66.07	-12.15	-4.61	TH
TMV8VY		79.51	1.15	0.59	79.78	1.56	0.59	GM
V8FVC6		76.58	-1.78	-0.93	76.38	-1.84	-0.70	LA
WNWEN3		81.33	2.97	1.54	81.82	3.60	1.37	LA
YBND3W		79.70	1.34	0.69	80.17	1.95	0.74	TH
ZUAN6L		77.74	-0.62	-0.32	77.48	-0.74	-0.28	PP

Summary Statistics	Sample GT71	Sample GT72
Grand Means	78.36 Gloss Units	78.22 Gloss Units
Std Dev Btwn Labs	1.93 Gloss Units	2.64 Gloss Units

Statistics based on 16 of 17 reporting participants.

Comments on Assigned Data Flags for Test #395

RPQH82 (X) - Extreme Data.

Key to Instrument Codes Reported by Participants

GA BYK-Gardner (model not specified)	GM BYK-Gardner micro-gloss
LA L & W Gloss - Autoline 300	LB L & W Gloss Tester Code 224
LF L & W Autoline 400	PP Technidyne Profile/Plus
TH Technidyne T480A	VM Valmet PaperLab (was Kajaani/Robotest)




Paper & Paperboard Interlaboratory Testing Program
Analysis 395
Specular Gloss at 75 Degrees - High Range
TAPPI Official Test Method T480

Report #3022G,
October 2019

Grand Mean Sample GT71 = 78.364
Gloss Units

Grand Mean Sample GT72 = 78.219
Gloss Units

ANALYSIS 395





Paper & Paperboard Interlaboratory Testing Program
Analysis 396
Specular Gloss at 75 Degrees - Low Range
TAPPI Official Test Method T480

Report #3022G,
October 2019

WebCode	Data Flag	Sample GU71			Sample GU72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
ARBF73		33.36	0.29	0.25	34.18	0.52	0.42	LA
FLNTKC		33.00	-0.07	-0.06	34.02	0.36	0.29	PP
H7Q9CM		33.85	0.78	0.67	34.98	1.32	1.06	PP
K2MBGC		33.65	0.58	0.50	33.94	0.28	0.22	GS
L9GV36		32.70	-0.37	-0.31	34.50	0.84	0.67	TH
PWA2DW		34.45	1.38	1.18	34.18	0.52	0.42	PP
Q88HHR		32.16	-0.91	-0.78	34.17	0.51	0.41	TH
V8FVC6		31.16	-1.91	-1.63	31.38	-2.28	-1.82	LA
XYAXJH		34.70	1.63	1.40	33.90	0.24	0.19	TH
ZLWGKC		31.63	-1.44	-1.23	31.35	-2.31	-1.85	ZT

Summary Statistics	Sample GU71	Sample GU72
Grand Means	33.07 Gloss Units	33.66 Gloss Units
Std Dev Btwn Labs	1.17 Gloss Units	1.25 Gloss Units
Statistics based on 10 of 10 reporting participants.		

Key to Instrument Codes Reported by Participants

GS	BYK-Gardner Glossgard II	LA	L & W Gloss - Autoline 300
PP	Technidyne Profile/Plus	TH	Technidyne T480A
ZT	Zehntner ZLR 1020		



Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019


Analysis 396

Specular Gloss at 75 Degrees - Low Range

TAPPI Official Test Method T480

Grand Mean Sample GU71 = 33.066
Gloss Units

Grand Mean Sample GU72 = 33.660
Gloss Units



If fewer than 20 laboratories are included in an analysis, a control ellipse will not be drawn on the two-sample plot.



Paper & Paperboard Interlaboratory Testing Program
Analysis 398
Grammage (Mass per Unit Area)
TAPPI Official Test Method T410

Report #3022G,
October 2019

WebCode	Data Flag	Sample GW71			Sample GW72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
38UPYX		89.32	-0.09	-0.17	102.8	-0.7	-1.29	ZZ
4AUDQT		89.90	0.49	0.95	104.6	1.0	1.81	ZZ
638U7P	X	88.75	-0.66	-1.28	1.0	-102.5	-183.81	ZZ
6UG9ZR		89.29	-0.12	-0.23	103.4	-0.2	-0.33	ZZ
7QCZ9M		88.81	-0.60	-1.17	103.6	0.1	0.13	ZZ
ARBF73		88.89	-0.52	-1.01	103.5	-0.1	-0.10	ZZ
B9EC38		89.44	0.03	0.05	103.9	0.4	0.70	ZZ
CG77DB		89.91	0.50	0.96	103.9	0.4	0.66	ZZ
CWHKWT		88.65	-0.76	-1.48	103.6	0.1	0.11	ZZ
GRQ6DM		88.86	-0.55	-1.07	102.6	-0.9	-1.69	ZZ
HRNR97		90.23	0.82	1.59	104.5	1.0	1.76	ZZ
JAJKT6	*	89.44	0.03	0.06	102.4	-1.1	-2.01	ZZ
JFA23A		90.20	0.79	1.54	103.8	0.2	0.38	ZZ
JGGGC2		88.93	-0.48	-0.93	103.2	-0.3	-0.54	ZZ
K2N2R2		88.96	-0.45	-0.87	103.2	-0.4	-0.68	ZZ
KB9GAA		90.65	1.24	2.41	104.3	0.8	1.38	ZZ
KPUK3Z		89.35	-0.06	-0.12	103.3	-0.3	-0.52	ZZ
KU4AWT		89.19	-0.22	-0.43	103.7	0.2	0.36	ZZ
L9GV36		89.80	0.39	0.77	103.4	-0.2	-0.32	ZZ
LZ4PHU		89.39	-0.02	-0.05	103.4	-0.1	-0.24	ZZ
N4UXJ7		89.66	0.25	0.49	104.1	0.6	1.02	ZZ
Q3ZYFR		89.52	0.11	0.22	103.5	-0.1	-0.11	ZZ
Q6KXGU		89.57	0.16	0.31	103.9	0.3	0.59	ZZ
Q88HHR		89.76	0.35	0.68	103.9	0.3	0.58	ZZ
QAU49T		89.75	0.34	0.66	104.1	0.5	0.95	ZZ
RMEZR3		90.03	0.62	1.20	104.2	0.7	1.24	ZZ
V2MVVN		89.09	-0.32	-0.62	102.8	-0.8	-1.40	ZZ
WMLJZP		88.72	-0.69	-1.34	103.7	0.1	0.22	ZZ
XYAXJH		89.04	-0.37	-0.72	102.8	-0.8	-1.38	ZZ
XZ7H4W		88.54	-0.87	-1.69	102.8	-0.7	-1.25	ZZ
ZLWGKC		89.41	0.00	0.00	103.5	0.0	-0.03	ZZ

Summary Statistics	Sample GW71	Sample GW72
Grand Means	89.41 g/sq m	103.54 g/sq m
Std Dev Btwn Labs	0.51 g/sq m	0.56 g/sq m
Statistics based on 30 of 31 reporting participants.		

Comments on Assigned Data Flags for Test #398

638U7P (X) - Extreme Data for Sample GW72.



Paper & Paperboard Interlaboratory Testing Program
Analysis 398
Grammage (Mass per Unit Area)
TAPPI Official Test Method T410

Report #3022G,
October 2019

Key to Instrument Codes Reported by Participants

ZZ Instruments No Longer Tracked




Paper & Paperboard Interlaboratory Testing Program

Report #3022G,
October 2019

Analysis 398 Grammage (Mass per Unit Area) TAPPI Official Test Method T410

Grand Mean Sample GW71 = 89.410
g/sq m

Grand Mean Sample GW72 =
103.54 g/sq m





Paper & Paperboard Interlaboratory Testing Program
Analysis 399
Sizing Test (Hercules Type)
TAPPI Official Test Method T530

Report #3022G,
October 2019

WebCode	Data Flag	Sample GX71			Sample GX72			Instr Code
		Lab Mean	Diff from Grand Mean	CPV	Lab Mean	Diff from Grand Mean	CPV	
2F6WTF		11.17	0.66	0.25	11.030	1.209	0.42	HE
2HBEVH		8.93	-1.58	-0.59	8.350	-1.471	-0.51	HE
2ZVZGU	X	15.80	5.29	1.98	9.710	-0.111	-0.04	XX
4FG9PC		8.59	-1.92	-0.72	8.410	-1.411	-0.49	HE
638U7P		11.30	0.79	0.30	11.100	1.279	0.44	HE
7FAVYK		9.78	-0.73	-0.27	9.150	-0.671	-0.23	HE
7QCZ9M	X	29.78	19.27	7.22	26.360	16.539	5.70	XX
9GF4XV		9.29	-1.22	-0.46	8.330	-1.491	-0.51	HE
AQFRRD		8.78	-1.73	-0.65	6.910	-2.911	-1.00	HE
AYDQZE		9.74	-0.77	-0.29	9.700	-0.121	-0.04	HE
EZRK66		13.25	2.74	1.03	13.660	3.839	1.32	HE
FAVA4K		7.37	-3.14	-1.17	6.610	-3.211	-1.11	HE
FLNTKC		16.60	6.09	2.28	15.820	5.999	2.07	HE
G42GMB	*	11.01	0.50	0.19	8.130	-1.691	-0.58	HE
G48UB8		8.94	-1.57	-0.59	8.360	-1.461	-0.50	HE
GFU3T7		9.45	-1.06	-0.40	9.750	-0.071	-0.02	HE
H7Q9CM		6.69	-3.82	-1.43	6.450	-3.371	-1.16	HE
HRNR97		14.09	3.58	1.34	12.910	3.089	1.06	HE
JN3EY3		12.10	1.59	0.60	9.810	-0.011	0.00	HE
K2N2R2		11.40	0.89	0.33	10.900	1.079	0.37	HE
KMZ78U	X	19.15	8.64	3.24	11.910	2.089	0.72	HE
LAUANT		10.50	-0.01	0.00	9.500	-0.321	-0.11	HE
MCFEXB		9.19	-1.32	-0.49	7.800	-2.021	-0.70	HE
QF3MA8		10.09	-0.42	-0.16	8.710	-1.111	-0.38	HE
TFVY7Y		10.96	0.45	0.17	10.260	0.439	0.15	HE
TMV8VY		10.07	-0.44	-0.16	10.360	0.539	0.19	HE
TVQCNZ		17.30	6.79	2.54	17.330	7.509	2.59	HE
VGJATW		6.03	-4.48	-1.68	4.620	-5.201	-1.79	XX
VQMFR6		7.80	-2.71	-1.01	7.300	-2.521	-0.87	HE
XYAXJH		13.30	2.79	1.05	13.900	4.079	1.41	HE

Summary Statistics	Sample GX71	Sample GX72
Grand Means	10.51 Seconds	9.82 Seconds
Std Dev Btwn Labs	2.67 Seconds	2.90 Seconds
Statistics based on 27 of 30 reporting participants.		



Paper & Paperboard Interlaboratory Testing Program
Analysis 399
Sizing Test (Hercules Type)
TAPPI Official Test Method T530

Report #3022G,
October 2019

Comments on Assigned Data Flags for Test #399

2ZVZGU (X) - Inconsistent in testing between samples.

KMZ78U (X) - Data for sample GX71 are high. Inconsistent within the determinations of sample GX71.

7QCZ9M (X) - Extreme Data.

Key to Instrument Codes Reported by Participants

HE Hercules Sizing Tester

XX Instrument make/model not specified by lab




Paper & Paperboard Interlaboratory Testing Program
Analysis 399
Sizing Test (Hercules Type)
TAPPI Official Test Method T530

Report #3022G,
October 2019

Grand Mean Sample GX71 = 10.508
Seconds

Grand Mean Sample GX72 = 9.8207
Seconds

ANALYSIS 399





Paper & Paperboard Interlaboratory Testing Program

**Report #3022G,
October 2019**

Analysis 399

Sizing Test (Hercules Type)

TAPPI Official Test Method T530

-End of Report-